


# Setting Infeed Loading Wheel

How to correctly set the pressure and clutch settings on the infeed loading wheel

 Difficulty **Hard**

 Duration **30 minute(s)**

## Contents

Introduction

Video overview

Step 1 - Check that the clutch is assembled correctly

Step 2 - Select a heavy profile for setting up

Step 3 - Move the x axis clear

Step 4 - Check the profile can slide to the machine easily

Step 5 - Activate the Wheel

Step 6 - Set the pressure

Step 7 - Attempt to slide the profile by hand

Step 8 - Try with power

Step 9 - Try with power and infeed clamps on

Step 10 - Final manual test with motor off


Step 11 - Fold over the castellation locknut

Comments

## Introduction

Setting the pressure and clutch tension on the loading wheel is critical for the reliable and accurate running of the machine. If set incorrectly, the profile will slip and not load correctly or will not give an accurate start position for the datum holes.

The goal is to set the system to a "goldilocks" zone where there is enough pressure and clutch tension to reliably load a bar, but not too much so the clutch limits any correctional movement from the gripper arm on loading.


 ...It has been demonstrated that the clutch can easily untighten if the castellation is not done up correctly. The video demonstrates how easy it is for the wheel to become loose.

## Step 1 - Check that the clutch is assembled correctly

The clutch should have a friction plate each side of the pulley wheel

## Step 2 - Select a heavy profile for setting up

Use the heaviest profile you can find - a full bar of door T or transom. Place it under the wheel so it can be fed into the machine.

 ...Ensure the infeed flights are out of the way.

## Step 3 - Move the x axis clear

Move the x axis to 4000mm so there is a clear test runway

---

## Step 4 - Check the profile can slide to the machine easily

Ensure there are no height spots or differences in height between the infeed and outfeed table that prevent the smooth transition of the profile into the machine

Activate the side and top infeed clamps with the profile inside, check again that it slides easily -the top and side clamps should be on 2 bar

---


## Step 5 - Activate the Wheel

Ensure the top and side infeed clamps are off  
Bring the wheel onto the profile

---

## Step 6 - Set the pressure

Pressure should be set to 1 bar - any more than this creates too much drag for the clutch wheel to overcome

 ...The wheel has considerable weight, it does not need much more from an additional cylinder

---

## Step 7 - Attempt to slide the profile by hand

The wheel clutch tension should be set so you can still manually push the profile and out of the machine. The wheel should turn (ie should not skid on the profile) but there should be obvious tension.

Adjust the clutch tension if to suit

---

## Step 8 - Try with power

With the wheel on the profile, try the wheel motor on  
The bar should drive in.  
If the clutch slips, turn motor off, tighten clutch, try again

---

## Step 9 - Try with power and infeed clamps on


Try same test again with the infeed clamps on.  
The clutch needs to just overcome the friction created by the side clamps

---

## Step 10 - Final manual test with motor off

Now the clutch has been tightened to overcome the infeed clamp forces, see if you can still slide the bar with the wheel done and the infeed clamps on.

It should be more difficult, but it should be possible to overcome the forces.

 ...If you cannot overcome the forces manually, then there is something wrong

---

If this manual test fails, there could be one or more of these problems:

- Too much down pressure on wheel
  - Clutch is too tight
  - Friction / tightness in a roller
  - A non-rolling part of the table or fence sticking out causing friction
-

## Step 11 - Fold over the castellation locknut



...This is a very important final step to prevent the clutch coming loose

