



A2001 - Light Curtain Timer

This tutorial will explain how to fit a timer into the light curtain and ES circuit.

 Difficulty **Medium**

 Duration **30 minute(s)**

Contents

Introduction

Step 1 - Removing Current Wiring

Step 2 - Adding in Timer Relay

Comments

Introduction

This step by step guide will explain how to wire a timer relay into the light curtain and estop circuit on the A2001 Autoflow.



Refer to
instruction manual



For maintenance
disconnect from...

High Voltage

Step 1 - Removing Current Wiring

