


Fichier:X252 Forward Clamp Out Sensor Setup Stuertz Infeed Sensor Diagram.jpg



1	Operating display	green
2	Signal display	yellow
3	TEACH-IN button	
4	Mode rotary switch	
5	Laser output	


Size of this preview:800 × 276 pixels.

Original file (846 × 292 pixels, file size: 43 KB, MIME type: image/jpeg)

X252_Forward_Clamp_Out_Sensor_Setup_Stuertz_Infeed_Sensor_Diagram

File history

Click on a date/time to view the file as it appeared at that time.

	Date/Time	Thumbnail	Dimensions	User	Comment
current	12:43, 26 January 2023		846 × 292 (43 KB)	Gareth Green (talk contribs)	X252_Forward_Clamp_Out_Sensor_Setup_Stuertz_Infeed_Sensor_Diagram

You cannot overwrite this file.

File usage

The following page links to this file:

X252 Forward Clamp Out Sensor Setup Stuertz Infeed