

# Input Definition 002 - InA Measure1

Input Definition 002 - InA Measure1


## Contents

Comments

[Back To Stuga Machine IO Dictionary - Inputs](#)

### Input Definition

Reference	002
Type	Input
Code	InA_Measure1
Description	On-arm flying measuring sensor 1
Used On	Autoflow
Function	Measuring sensor on the autoflow arm, used to determine the end of the profile when measuring bar lengths at the start of the loading cycle
Sensor Type	Laser sensor
Adjustment	Adjust for profile position and colour See Setting Profile Detection Laser Sensor
See Also	Input Definition 003 - InA Measure2 TB0189 Narrow Profile Next to Wide on Infeed Table TB0315 Fitting Autoflow Dark Profile Sensor

 ...If this sensor fails, it can very easily be swapped with sensor no2, simply by swapping the wires. However, this depends on sensor 2 being set up correctly