

Input Definition 004 - InA GZHome

Input Definition 004 - InA_GZHome

Contents

Comments

[Back To Stuga Machine IO Dictionary - Inputs](#)

Input Definition

Reference	004
Type	Input
Code	InA_GZHome
Description	Gripper Z axis home / datum input
Used On	Autoflow
Function	provides a zero referencing point for the GZ axis on the gripper
Sensor Type	Proximity Sensor
Adjustment	Adjust distance to detected surface - should be < 1mm
See Also	Common Issue - Autoflow GZ Datum Sensor Bracket Bent

