

Input Definition 010 - InA GXHome

Input Definition 010 - InA_GXHome

Contents

Comments

[Back To Stuga Machine IO Dictionary - Inputs](#)

Input Definition

Reference	010		
Type	Input		
Code	InA_GXHome, DATX		
Description	X axis home / datum input		
Used On	Autoflow	Flowline / Microline / ZX3 / ZX4	Ecoline
Cable Marking	X010	X7	X0
Function	Provides a zero referencing point for the main X axis		
Sensor Type	Proximity Sensor	Proximity Sensor	Proximity Sensor
Adjustment	Adjust distance to detected surface - should be < 1mm		
See Also			
Picture			