

Installing Jetsym Project

How to download a Jetsym project / program

 Difficulty **Medium**

 Duration **5 minute(s)**

Contents

Step 1 - Open Jetsym Workspace

Step 2 - Build the project

Step 3 - Check Build Dialog for errors

Step 4 - Download Program

Step 5 - Power Cycle PLC

Comments

Step 1 - Open Jetsym Workspace

Step 2 - Build the project

Build->Build

Step 3 - Check Build Dialog for errors

Step 4 - Download Program

Build->Download Program



...DONT download the program while the machine is running

Progress will be shown in Build Dialog

Wait until it is finished

Step 5 - Power Cycle PLC

Switch on an off with buttons