

Parts Identification - Cill Support Blocks

How to identify the cill pads used on the Stuga Ancillaries Saw

Contents

Check the Profile Range

Handing

Selection

Comments

Check the Profile Range

The cill blocks come in height and width variants to suit various cills. The height of the block lifts the "body" of the cill off the deck so it lays flat to allow angled sawing. This means the height must be higher than the drip nose depth.

Diagram shows the position of the cill support block to bring the cill to a horizontal plane



The width of the block is less fussy, but some very wide cills may need a wider support block to prevent them twisting on loading

⚠ ...Regrettably, there is no hard and fast rule with Cill blocks. For "new" cills" it can be experimental. A table below lists the profile systems that have been successfully implemented along with the cill type

Handing

The cill supports are handed, so be sure to choose the correct hand for the machine

Selection

The parts list for Cill Pads is maintained in this Monday Board

Selection Chart

BuildNo	HAND	Profile System	Codes	Cill Pads
S059	Std	Eurocell	AC150 AC180 AC225	D0001897 D0001898
S012	Std	Rehau	Rehau 246330 150mm Rehau 246340 180mm Rehau 503940 225mm	D0001897-16 D0001898-16

See Also Ancil Saw Setup Guidance

