

Sprint Drive C0000253 Setting Up

How to set up a Sprint Drive

Contents

Comments

Used on later Ecolines with Baldor control system

Now obsolete

The following notes are the remaining setup instructions

this needs to be supplied with 10v (-sp/com and +sp)

Also needs 36v supplied (V- and V+)

Then connect a load (Bulb) to the 24v (A+ and A-) and rotate pot at top (Max) until 24v dc is achieved (+/- 5%)

9v = 21.6 v