

# Subassembly Numbering Policy

Policy for the part numbering of subassemblies

## Contents

- Subassembly Numbering Policy
- Part Numbering Policy
- Cable Numbering Policy -Autoflow
- Comments

# Subassembly Numbering Policy

Rnnnnnnn[[]]-[OH]

nnnnnnn	7 Digit Part Number	
[[]]	Optional Letter	
	b-z	Version number. Major version change of assembly, fit and / or function has changed. Not backwards compatible
	R	Refurb version of a subassembly
	X	Service exchange part – generally 50% of new price
	P	Parts only (copy of a service subassembly with labour removed for accurate costing)
[OH]	Optional flag to signify opposite hand version of a subassembly. The letters OH should also appear at the end of the description field.	

# Part Numbering Policy

Xnnnnnnn-[OH]

X	Single letter Part number to standard categories
nnnnnnn	7 Digit Part Number
[OH]	Optional flag to signify opposite hand version of a subassembly. The letters OH should also appear at the end of the description field.

Suffixes are added to the part number (eg SX or X for service exchange, or to identify a similar part, with a modified design for other uses)

# Cable Numbering Policy -Autoflow

\*\*\* Now obsolete \*\*\*

CB-[nn][X/Ynnn]M[[]]

nn	2 digit cable number local to module
X/Ynnn	IO cable number (eg X003, Y120), not local to module

M	Module Letter	
[I]	Optional Letter	
	b-z	Version number. Major version change of cable, Length and / or connectors have changed