

ZX4 Transfer Table

Operation of the ZX4 Transfer Table.

Contents

[Transfer Table](#)

[Comments](#)

Transfer Table

The Transfer Table provides the link between the Multihead and the Saw Centre. The profile is carried across the transfer table to the Saw infeed.