

Upgrading To Version 5 Software 64 bit

How to upgrade a Nextmove / TwinCAT 3 machine to the latest Version 5 software (64 bit)

Contents

Comments

Download and install Mint version 5680
Copy the multi folder to a new folder DDRIVE
Copy Saw Folder from source machine
Share the folder SAW for everyone - Full if using a separate saw
Delete contents of multi folder
Copy latest version 5 full install folder to \multi
Edit masterdir.saw
c:\ddrive\
c:\saw\ (if this is a Nextmove machine)

messages.saw to c:\ddrive
Settings.mul in flowops - replace "multi" with "DDRIVE"

Run mint workbench. If Error:2333 appears, follow the procedure here

Ensure the latest mnt file is downloaded and run on the controller

 ...Ensure the Control Systems Log is updated with the date and the software versions currently installed

Control Systems Log