

# RMZX503 ZX5 Guard To Floor Height

Closing the guard to floor height on a ZX5 machine to prevent users crawling under guard

## Contents

Objective

Procedure

Testing

Completion

Comments

## Objective

To improve the ZX5 operator/ maintenance safety by

- Decreasing the gap from floor base of mesh guard to <180mm to comply with BS EN ISO 13857
- Use wire cable

## Procedure

Step	Description	Photo	
1	Drill fixing holes for cable eyelets		
2	Fix hook on wire end		
3	Thread through eyelets		
4	Cut to length and fix hook		
5	Fix with tensioning system		
6	Repeat for other side		

## Testing

Ensure the cable is tensioned and secure

## Completion

This modification is expected to take no longer than 2 hours to complete.

Completion is when:

- Testing completed
- Device Magic app updated for this task, with time taken and photo evidence recorded